



DOUBLE K ELECTRONICS RESTRAINER

COW RESTRAINER OPTIONS

COWS STILL MILKING AT EXIT ON ROTARY PLATFORMS?

Double K Electronics have four options to deal with the cow still milking at the exit stage.

Option One:

RTO:(Remote Take Off). With Automilker installation, the RTO knows if the cow is still milking at a point close to the exit and shuts the Automilker off which in turn takes the cups off even if the the cow has not finished milking. If this happens regularly, then the platform may be moving too fast. The remote display will flash showing the number of lights that were on at take off time.

Option Two

Cow Restrainers without cup removers:

The bail restrainer can be operated manually by squeezing the air bulb for down and squeeze again for up. You don't need cup removers to operate manually.



Option Three:

Cow Restrainers with Automilker installation

(i) If the cow does not give sufficient milk, or cups get kicked off before the 2 minute 40 sec let down time, the Automilker ram will hang the cups up and the cow restrainer will stay down preventing the cow from exiting. This allows the milker to refit the cups for another rotation.

Option Four

Cow Restrainers with any type of cup removers:

The cow restrainers ram is tapped into the vacuum of the cup remover ram, so when the cups are taken off and hung up, the restrainer will be in the raised position